



CORDE ELASTICHE

AVVERTENZE:

- Non posizionare le corde su angoli acuminati o superfici taglienti.
- In caso di frenata brusca o in presenza di forte vento, fare attenzione alla tenuta delle corde, ricontrollandone la tensione.
- I carichi soggetti a forte attrito del vento e comunque di un certo peso, vanno ulteriormente assicurati.
- Le corde elastiche sono particolarmente adatte per stabilizzare teli allentati.
- Queste corde elastiche non sono adatte per il sollevamento e il traino di carichi.
- Indossare occhiali protettivi e non tirare la corda verso se stessi. Tendere la corda fino max 70% della sua lunghezza.
- Evitare di utilizzare le corde in condizioni di temperatura al di sotto di -30°C o al di sopra di +70°C e non trattare con prodotti chimici

STOCCAGGIO/MANUTENZIONE:

non conservare nelle immediate vicinanze di fonti di calore sopra i 90°C. In caso di eventuali rotture, danneggiamenti o smagliature, non utilizzare più la corda, ma sostituirla con una nuova. Le corde danneggiate dall'azione del calore (deformazione, ecc.) o dall'impiego di materiali aggressivi/pericolosi (strappi, tagli, corrosione,...), devono essere controllate attentamente prima di un nuovo utilizzo. Conservare le corde in ambienti asciutti e poco riscaldati, al riparo dalla luce diretta del sole e lontano da fuochi e sostanze chimiche.



ELASTIC ROPES

WARNINGS:

- Don't place the ropes on sharpen edges or pointed surfaces.
- In case of sudden braking or strong wind, pay attention to the ropes holding, by checking the tension again.
- Loads subject to the wind action, must be further assured.
- Elastic ropes are particularly suitable for assuring loose lenghts.
- These ropes are not suitable for loads lifting neither towing.
- Wear protective goggles and do not pull the rope to yourself. Stretch the rope up to 70% of its length.
- Avoid to use the straps when in temperature conditions below -30°C or above +70°C, and avoid to or treat with chemicals

STORAGE/MAINTENANCE: do not store near heat sources above 90°C. In case of any breakage, damage or overstretch, do not use the rope anymore, but replace it with a new one. Ropes damaged due to heat (i.e.: deformation,...) or due to the use of aggressive/hazardous materials (leading to tears, cuts, corrosion,...) must be checked carefully before a new use. Keep the ropes in dry and low-heated places, away from direct sunlight, from flames and chemicals.